

Quick Installation Guide

Congratulations on the purchase of your new ACN Digitally Enhanced Cordless Phone. Please follow these basic instructions to install your cordless phone and use with your ACN Video Phone. Please refer to the enclosed User Manual for more details on using your cordless phone.

Before you get started:

Ensure your cordless phone and power video phone cords are connected to a 120V AC wall outlet. Be sure the cordless phone is fully charged (at least 16 hours) before connecting to your video phone. Instructions for connecting and charging your cordless phone can be found in the User Manual.

1. Connect one end of the telephone cord to the telephone line jack on the cordless phone base station
2. Connect the other end of the telephone cord to the phone port on the back of your video phone.



Congratulations! You have successfully connected your cordless phone.

Note: If you did not transfer your current number to your ACN Video Phone, one of your cordless phones will need to be connected to your existing phone service to receive incoming calls to your existing number. To use the video feature on your video phone, you must be in front of the video phone. Cordless phones do not have video capability.

Your ACN Digitally Enhanced Cordless Phone comes with one (1) cordless base station plus one (1) pre-registered extension. You may purchase additional extensions (up to 11). Each extension must be registered to the base before using. Refer to the User Manual for detailed instructions.

If you experience difficulties installing your ACN Digitally Enhanced Cordless Phone, please contact ACN Digital Phone Technical Support, US 1-888-414-1958 or Canada 1-866-913-3445.